




SIDE GRIP JOYSTICK



OMS Vibro Website



OVR SG Video




OMS Pile Driving Equipment

✉ oms@omsvibro.com


in f X p / omsvibro

OMS Side Grip Joystick - Brochure
OMS has the right to change indicated technical data without prior notice.
© All rights reserved.

www.omsvibro.com

ÖZKANLAR
GRUP

Technical Specifications



PLC UNIT



PLC Unit is mounted on side grip vibro hammer. This unit manage all OVR SG functions like opening, closing, rotating and vibrating.

DISTRIBUTION BOX



Distribution Box is located inside the excavator cabinet. Joystick, PLC Unit, crusher valve and power supply are connected to this box.

JOYSTICK



Joystick is used for controlling side grip vibro hammer functions.

Control System of Side Grip Vibro Hammer

