

CONTROL SYSTEM OF SIDE GRIP VIBRO HAMMER



PLC UNIT



PLC Unit is mounted on side grip vibro hammer. This unit manage all OVR SG functions like opening, closing, rotating and vibrating.

DISTRIBUTION BOX




Distribution Box is located inside the excavator cabinet. Joystick, PLC Unit, crusher valve and power supply are connected to this box.

JOYSTICK



Joystick is used for controlling side grip vibro hammer functions.



SIDE GRIP JOYSTICK

